Section:	eRadHealth Menu
Role	
What is your r	role?
Note:	If you are acting as an agent of the actual manufacturer, please select your role, for example, Importer or Consultant. Later in the report, under Manufacturer Data, you will be prompted to enter both manufacturer and submitter information.
Submissio	n Information
FDA or Sta	ate Inspector
Abbreviate	ed Report Applicability
OEM Lase	er Applicability
Section:	: Manufacturer Data

Introduction

# **Electronic Product Radiation Safety Reporting Form**

This software application is intended to automate the hard copy product reporting forms in the effort of the Center for Devices and Radiological Health (CDRH) to become capable of accepting electronic submissions from industry and to improve our review process. This FDA Electronic Submission (eSub) software is the next version of the application developed to allow us to accept all Radiological Health reports and other submissions electronically and improve the ability of CDRH to accomplish its mandated product and industry evaluations in a timely and efficient manner.

All electronic reports and correspondence can either be transferred to CD and mailed to the address below, or can be sent via the FDA Electronic Submissions Gateway to CDRH. If you follow instructions to set up an account with the FDA Gateway, when you submit through it you will receive your acknowledgement email message with Accession Number within minutes!

Information about the FDA Electronic Submissions Gateway can be found at <a href="www.fda.gov/esg">www.fda.gov/esg</a>. Please contact the Gateway Helpdesk with your questions about that system.

Electronic submissions on CD should be mailed directly to the Document Control Center at:

U.S. Food and Drug Administration Center for Devices and Radiological Health Attn: eSubmitter Team Document Mail Center - WO66-0609 10903 New Hampshire Avenue Silver Spring, MD 20993-0002

Submissions received in the mail on CD will be processed within a few days of receipt.

You should be familiar with the regulatory requirements for radiological products at <a href="www.fda.gov/cdrh/radhealth/">www.fda.gov/cdrh/radhealth/</a> and medical devices available at <a href="www.fda.gov/cdrh/devadvice/">www.fda.gov/cdrh/devadvice/</a>. If you have specific questions about the regulations, please contact us at: <a href="DSMICA@fda.hhs.gov">DSMICA@fda.hhs.gov</a>.

If you have specific questions regarding this software, please contact the eSub team by email at: eSubmitter@fda.hhs.gov.

Thank you for using our electronic product reporting software. Please communicate your comments and suggestions to the eSub team as often as you like.

Thank you for your continued support of the FDA Electronic Submission Program (eSub).

General Information

# General Information for Radiological Health Products

Manufacturers of products subject to performance standards under the Federal Food, Drug, and Cosmetic Act (FFDCA), Chapter V, Subchapter C - Electronic Product Radiation Control are required to furnish various reports to the Center for Devices and Radiological Health (CDRH).

The Radiological Health staff, CDRH developed this software application for the Product and Annual reports. This application will assist manufacturers of electronic products that emit radiation in providing adequate reporting of radiation safety testing and compliance with federal performance standards. Title 21 of the Code of Federal Regulations (CFR), Parts 1002 and 1003 specify Reporting and Notification requirements 1,2,3.

Reports submitted on radiation safety of electronic products must follow the appropriate form (21 CFR 1002.7). This software application serves the same report responsibility, so long as the submitter or manufacturer prints out the cover letter and sends it in along with the CD containing the report files. The submitter of the report will receive an acknowledgment letter (or email message) with the

accession number that CDRH assigns to the report. Please reference this accession number in the future when providing additional information about this model family in either a supplement or the annual report. If a report is incomplete or inadequate CDRH may reject it and return it for completion. CDRH will not enter a rejected report into our database.

### CDRH DOES NOT APPROVE THESE REPORTS OR THE PRODUCTS BEING REPORTED.

It is the manufacturer's responsibility to certify that their products comply with all applicable standards (21 CFR 1010 - 1050), based on a testing program in accordance with good manufacturing practices. Prior to the shipment of products in interstate commerce, 21 CFR 1002 requires the manufacturer to submit the product and Annual Reports and to comply with all applicable importation requirements (21CFR 1005). If there are deficiencies, CDRH may disapprove the firm's quality control and testing program, determine that the product contains a radiation defect, or determine that the product fails to comply with a standard. CDRH will notify the manufacturer if we make such a determination. CDRH may require the manufacturer to cease introduction into U.S. commerce until deficiencies are corrected, and to initiate a corrective action program (21CFR 1003 - 1004) for products already introduced into commerce.

CDRH can now accept and process 'CeSub' electronic submissions at this time, if all attachments are PDF files only, and the cover letter is printed out and included with a real signature. Translate any text that appears in a language other than English into English in a complete and accurate manner. Keep a copy (save a copy to your hard drive) of the completed report in your records.

We are providing our new software applications for the old reporting forms upon request during this beta testing period of development in Spring, 2005. Other regulatory information is still available on the Internet under <a href="https://www.fda.gov/cdrh/radhealth/">www.fda.gov/cdrh/radhealth/</a>. No copyright exists for these forms.

Reproduce these forms as needed. If you would like to comment on the reporting forms, website, or future electronic submissions, you may direct the comments to **cdrhesub@cdrh.fda.gov**.

A complete Product Report is required for each product model or model family. Product Reports are now more generally referred to as Radiation Safety Reports to distinguish the Radiological Health submissions from medical device submissions. CDRH suggests that a complete report on one model of a family be submitted, with a separate Supplemental Report for each of the other models in the family. The Supplemental Report should respond in detail to the parts of the form where there are differences to report, referencing the number of the affected item. Items that are unchanged will still appear in the supplement from the original report.

When new models of a product are introduced, if the models satisfy the criteria for an established reporting exemption or if the new models do not involve changes in radiation emission or performance requirements, then the manufacturer need not report the models prior to introduction into commerce. Rather, the manufacturer is only required to identify them in the annual report, or in quarterly updates to the annual report. Quarterly updates to annual reports may be submitted using the Annual Report software included in this application. [See 21 CFR 1002.13(c).]

All symbols, units, and unusual terms in the report must be adequately defined and consistently used. Please use the terms as defined in Section 1040.10(b) and in the IEEE Standard Dictionary of Electrical and Electronic Terms (IEEE Std. 1001972 and ANSI C42.1001972).

**Definitions** 

# **Definitions for Rad Health Products**

### **Manufacturers**

Manufacturer is any person or organization engaged in the business of manufacturing, assembling, or importing of electronic products (21 CFR1000.3(n)). Manufacturers of electronic products subject to 21 CFR1000-1050 must:

- Design and manufacture their products to be in compliance with applicable performance standards;
- Test their products to assure compliance;
- Certify compliance of their products;
- Maintain test and distribution records and a file of correspondence concerning radiation safety, safety complaints, and inquiries;
- Use the published reporting forms or electronic software application to submit reports to CDRH, including Product reports describing the manner of compliance of the product design and testing program and Annual Reports summarizing their compliance testing;
- Report accidental radiation occurrences (i.e., possible, suspected, or known exposures);
- Report any radiation defects or noncompliances; and
- Recall (i.e., repair, replace, or refund the purchase price of) defective or noncompliant products.

### **Accidental Radiation Occurrences**

An accidental radiation occurrence means a single event or series of events that has/have resulted in injurious or potentially injurious exposure of any person to electronic product radiation as a result of the manufacturing, testing, or use of an electronic product.

### **Importers**

Importer is any person of organization engaged in the business of importing electronic products. An importer is considered to be a manufacturer. The requirements for Manufacturers given above also apply to importers if the requirements have not been done by the foreign manufacturer.

### **United States Agent for Foreign Manufacturers**

Every manufacturer of electronic products, prior to offering such product for importation into the United States, shall designate a permanent resident of the United States as the manufacturer's agent upon whom service of all processes, notices, orders, decisions, and requirements may be made for and on behalf of the manufacturer as provided in section 536(d) of the Radiation Control for Health and Safety Act of 1968 (21U.S.C. 360mm(d)) and this section. The agent maybe an individual, a firm, or a domestic corporation. For purposes of this section, any number of manufacturers may designate the same agent.

# From The Federal Food, Drug, and Cosmetic ActSec 536 [21 U.S.C. 360mm](d) Designation of agent for purposes of service

It shall be the duty of every manufacturer offering an electronic product for importation into the United

States to designate in writing an agent upon whom service of all administrative and judicial processes, notices, orders, decisions, and requirements may be made for and on behalf of said manufacturer, and to file such designation with the Secretary, which designation may from time to time be changed by like writing, similarly filed. Service of all administrative and judicial processes, notices, orders, decisions, and requirements may be made upon said manufacturer by service upon such designated agent at his office or usual place of residence with like effect as if made personally upon said manufacturer, and in default of such designation of such agent, service of process, notice, order, requirement, or decision in any proceeding before the Secretary or in any judicial proceeding for enforcement of this part or any standards prescribed pursuant to this part may be made by posting such process, notice, order, requirement, or decision in the Office of the Secretary or in a place designated by him by regulation.

Sec. 531 [21 U.S.C. 360hh] (1) the term **"electronic product radiation"** means:

- (A) any ionizing or non-ionizing electromagnetic or particulate radiation, or
- (B) any sonic, infrasonic, or ultrasonic wave, which is emitted from an electronic product as the result of the operation of an electronic circuit in such product.

Sec. 531 [21 U.S.C. 360hh](2) the term **''electronic product''**means:

- (A) any manufactured or assembled product which, when in operation,(i) contains or acts as part of an electronic circuit and (ii) emits (or in the absence of effective shielding or other controls would emit) electronic product radiation, or
- (B) any manufactured or assembled article which is intended for use as a component, part, or accessory of a product described in clause (A) and which when in operation emits (or in the absence of effective shielding or other controls would emit) such radiation.

Burden to Industry

# **Paperwork Reduction Act Statement**

Public reporting burden for this collection of information is estimated to average 26 hours per response, including the time for reviewing instructions, searching existing data sources, gathering and maintaining the data needed, completing, and reviewing the collection of information. Send comments regarding this burden estimate or any other aspect of this collection of information, including suggestions for reducing this burden to:

U.S. Food and Drug Administration Center for Devices and Radiological Health Document Mail Center - WO66-0609 10903 New Hampshire Avenue Silver Spring, MD 20993-0002

"An agency may not conduct or sponsor, and a person is not required to respond to, a collection of information unless it displays a currently valid OMB control number."

### Manufacturer and Report Information

#### Information:

This general report requests names, addresses, phone numbers, etc. for your firm, various officials of your firm, consultants who may assist in preparing the report, parent firm (if any), importer and designated agent (for foreign firms). Some of this information is mandatory and its absence will prevent you from completing the report submission. You can check for missing data using the "Missing Data" report from the "Output" menu.

If you are acting as an agent or consultant for another firm who is certifying the product (or laser light show), please enter the certifying manufacturer and list yourself as the report submitter, below.

#### Information:

Attention: Variance Applicants

If you are acting as an agent or consultant for, or on behalf of, or filing for, a company that will be manufacturing or producing a Class IIIb or IV projector or laser light show or both which require an approved variance, the following explanations may provide further clarification.

Manufacturer: This is the firm or company who is requesting the variance, will certify the product or show, and will be the holder and owner of the variance. This is not the agent or consultant who may be filing this report or Variance request for the manufacturer; that agent may be the submitter, identified in a later screen.

Responsible Individual: This person works for the Manufacturer and is responsible for compliance of the projector and/or show. In the case of laser light shows, he or she may be the company president, CEO, or the laser light show head operator or a manager who oversees the shows.

Reporting Official: This person works for the Manufacturer and is responsible for reports, recordkeeping, and submitting FDA required documents and correspondence.

#### Manufacturer Responsible for Product Compliance

٨	ı	ıtα	ď

This is the firm that takes responsibility for certification that the product meets the performance standard. This firm develops and maintains the quality control and testing program that is the basis for the certification of this product. Additionally, this firm usually is the owner of the product design and manufacturing process design.

Select the Manufacturer's address from the Establishment Address book:		
Establishment Information:		
Establishment Name		
Division Name		
Home Page		
Physical Location:		
Address		
Telephone Number		
Fax Number		
Mailing Location:		
Address		

### Responsible Individual

Note:

The responsible individual is the highest level and most responsible individual affiliated with this establishment.

Select the Responsible Individual from the Contact Address book:

Contact Information:		
Contact Name		
Occupation Title	Occupation Title	
Email Address	Email Address	
Establishment Inform	ation:	
Establishment Name		
Division Name		
Physical Location:		
Address		
Telephone Number		
Fax Number		
Mailing Location:		
Address		
Manufacturer's F	Report	ting Official
Note:	and qu	s the person at the manufacturing facility that is knowledgeable and responsible for addressing all aspects of the testing uality control procedures for certification as reported to FDA in the product report. Documentation of changes intesting uality control procedures submitted to FDA must be signed by this individual.
Select the Reporting	Official f	from Contact Address book:
Contact Information:		
Contact Name		
Occupation Title		
Email Address		
Establishment Inform	ation:	
Establishment Name		
Division Name		
Physical Location:		
Address		
Telephone Number		
Fax Number		
Mailing Location:		
Address		
Report Submitte	r	
	T'	
Note:	docum	ubmitter maybe a consulting individual or firm providing assistance in report preparation and maintenance. All nents prepared by the submitter must have the manufacturer's reporting official signature for authenticity of submitted

doc	rumentation.				
Select the Submitter from	the Contact Address book:				
Contact Information:	Contact Information:				
Contact Name					
Occupation Title					
Email Address					
Establishment Information					
Establishment Name					
Division Name					
Physical Location:					
Address					
Telephone Number					
Fax Number					
Mailing Location:					
Address					
Comments:					
Internal Reference Number	or:				
Parent Establishme	nt				
Is there a parent establish	ment?				
	•				
Select the Parent Establish	hment and Contact from the Contact Address book:				
Contact Information:					
Contact Name					
Occupation Title					
Email Address					
Establishment Information:					
Establishment Name					
Division Name					
Physical Location:					
Address					
Telephone Number					
Fax Number					
Mailing Location:					

Address				
Manufacturer Designated United States Agent				
Manufacturer Designated United States Agent				
Note:	Manufacturers exporting to the U.S. must designate a U.S. agent, see 21 CFR 1005.25.			
Is there a United State	es agen	t that has been designated by the manufacturer?	[L]	
Written Agreeme	ent			
Item: 1 (could conta	in up to	10 items with none required)		
Note:	If any	of the required responses below do not apply to your designated agent, enter 'NOT APF	PLICABLE' or 'NA.'	
Select the Designated	d Agent	from the Contact Address book:		
Contact Information:				
Contact Name				
Occupation Title				
Email Address	Email Address			
Address				
Establishment Name				
Division Name				
Address				
Telephone Number	Telephone Number			
Fax Number				
Attach a copy of writte	Attach a copy of written agreement with the designated U.S. agent:			
[Multi-Line Plain Text]				
File Attachment				
Importer				
Item: 1 (could contain up to 10 items with none required)				
Select the Importer from the Contact Address book:				
Contact Information:				
Contact Name				
Occupation Title				
Email Address				
1			l l	

Establishment Information:				
Establishment Name				
Division Name				
Physical Location:				
Address				
Telephone Number				
Fax Number				
Mailing Location:				
Address				
Additional Manufactu	ring Locations			
Item: 1 (could contain up t	o 100 items with none required)			
•				
Producodes proces	If any of the products certified in this report are manufactured at locations other than listed in the Manufacturer Responsiblefor Product Compliance section, then the names, addresses, and FDA registration numbers should be provided. In addition any codes used on labels to identify a manufacturing location must be provided. Each factory location must assure all production procedures are followed identically step by step as provided in this report. If the procedures are not the same then separate reports should be filed.			
Select the Manufacturer Add	lress from the Establishment Address book:			
Establishment Information:				
Establishment Name	stablishment Name			
Division Name				
Home Page				
Physical Location:				
Address				
Telephone Number				
Fax Number				
Mailing Location:				
Address	Address			
Comments:	Comments:			
Code used on identification	abels:			
	<b>'</b>			
Section: Product	Section: Product Data			
Product and Model Id	antification			

At this time we are only accepting electronic versions of reporting guides contained within this software. Other reporting Note: guides that are not yet electronic are available for downloading from http://www.fda.gov/cdrh/comp/eprc.html. Product Type Reported Report Information Is this submission a supplement to an Annual Report submitted previously for the same reporting year? [L] Provide the Accession Number of the original report for which this is a supplement: (Note: Do not enter any Device Premarket Application or Notification document number here, such as PMAs, 510(k)s, IDEs, Please verify that your accession number matches the report type that is being filed. The third character of your accession number must correspond with its associated report type as shown in the table below: Third Character: **Report Type Description: Initial Product Report** Model Change Product Report 3 Annual Report 8 Abbreviated Report Variance Request Α R Laser OEM Registration and Listing Report [L] Are you requesting a new variance, a renewal, extension or amendment to a previous variance? If you are requesting a renewal, extension, or amendment, please provide the variance number that was issued by CDRH. If you are requesting a new variance, renewal, extension, or amendment, you must file a Variance Request separate from this Stop: report. To do this, open a new report (File > New) and select either "Laser Light Show Variance Request" or "Variance Request, Other" as your Type of Submission in the Submission Information Screen. If you select "Variance Request, Other" you must select the product for which you are requesting a variance at the end of the screen. Special Considerations Note: Check all items in this section that may apply to this submission. Noncompliances or Defects Does this document or any of its attachments contain: [L] A self-declaration or notification of noncompliance or defect? Provide an explanation:

[Multi-Line Plain Text]

### Responses to Noncompliances or Defects

Does this document or any of its attachments contain and of these responses concerning noncompliances?			
A refutation of noncompliances?			
A request for an exemption from notification?			
Corrective action plans you may be conducting?			
A description of any design changes that correct noncompliances for future production?			
Provide an explanation:			
[Multi-Line Plain Text]			

### **Exemption Requests**

Does this document or any of its attachments contain:			
Exemption of a product for Q	exemption of a product for government use from a standard (1010.5)?		
Exemption for products for Q	Exemption for products for government use from reporting and recordkeeping (1002.51)?		
Special exemption of produc	Special exemption of products from reporting and/or recordkeeping (1002.50)?		
Request for approval of alte	Request for approval of alternate labeling?		
Application for alternate test procedures (1010.13)? [L]			
Provide an explanation:			
[Multi-Line Plain Text]			
Attach any necessary files.	Attach any necessary files.		
[Multi-Line Plain Text]	[Multi-Line Plain Text]		
[Single File Attachment (.pdf, .jpg, .gif, .tif, .avi, .wmv, .xpt, .xml, .dtd, .sgml, .mol, .xls, .csv, .zip)]			

### Variance Requests

Message:	Click the plus sign to list the requirements from which you are requesting a variance.				
This submission inc	This submission includes an application for a variance from certain requirements.				
Item 1					
Item 2					
Item 3	tem 3				
Provide an explana	Provide an explanation and attach supporting files, if necessary. Click on the plus sign below to attach files.				
Details [HTML Text]		HTML Text]			

File Attachment	[Multiple File Attachments (.pdf, .jpg, .gif, .tif, .avi, .wmv, .xpt, .xml, .dtd, .sgml, .mol, .xls, .csv, .zip)]
The el the Me  U.S. F Cente. Attn: e Docum 10903 Silver Additio Food a Divisio 5630 I	I Variance requests, two submissions must be made to the FDA.  Idectronic version should be submitted following the Packaging Files for Submission instructions located under Output in enu bar, and explained in subsection 4.3 of the User Manual. If sending a CD & submittal letter, please mail to:  Food and Drug Administration refor Devices and Radiological Health essubmitter Team ment Mail Center - WO66-0609  8 New Hampshire Avenue Spring, MD 20993-0002  Fonally, a paper version (hard-copy) of the signed Variance request document should be submitted to:  and Drug Administration on of Dockets Management (HFA-305)  Fishers Lane, Room 1061  ville, MD 20857

### Responses to Communications from FDA

Does this document or any of its attachments contain:			
A response to an inspection?	[L]		
What was the date of the inspection?	[Date]		
A response to a warning letter from the Food and Drug Administration (FDA)?	[L]		
What was the date of the Warning Letter?	[Date]		
A response to a report review inquiry from the Center for Devices and Radiological Health (CDRH) (the inquiry may have been in the form of a letter, email, or phone call)?	[L]		
What was the date of the inquiry?	[Date]		
A response to any other communication from FDA?	[L]		
What was the date of the communication?	[Date]		
Provide an explanation:			
[Multi-Line Plain Text]			

### Additional Information

Is there any other relevant information or additional comments that would help expedite the review of this submission? Click the plus sign below to attach any supporting files.		
File Attachment [Multiple File Attachments (.pdf, .jpg, .gif, .tif, .avi, .wmv, .xpt, .xml, .dtd, .sgml, .mol, .xls, .csv, .zip)]		
Details	[HTML Text]	

### Private Labeling

Is the product sold by other companies under different brand names?	[L]
---	-----

Private Labeling-Table			
Item: 1 (could contain up to 20 items with 1 required)			
a			
Give the name and address	of the manufacturer:		
Establishment Information:			
Establishment Name			
Division Name			
Email Address			
Address			
Address			
Telephone Number			
Fax Number			
Give the firm establishment r	egistration number of the manufacturer listed above (if known):		
	odel designations in the following table by clicking on the Add button. If	you prefer to attach a file, please click on the	
Item 1			
Item 2			
Item 3			
List of Brand Names and/or I	Model Designations		
File Attachment	[Single File Attachment (.pdf, .jpg, .gif, .tif, .avi, .wmv, .xpt, .xml, .dtd, .	sgml, .mol, .xls, .csv, .zip)]	
Details	[HTML Text]		
The Original Equipment Man	ufacturer (OEM) accession number (if known):		
Explain how the brand name	s and model designations correspond with your own brand names and	model designations:	
[Multi-Line Plain Text]			
Medical Devices			
Provide the premarket 510(k), IDE, HDE, PDP, or PMA filing numbers related to this medical product, if one of these numbers has been assigned by FDA yet.			
[Multi-Line Plain Text]			
If it has not been assigned yet, provide an explanation and submit it as soon as you receive such a filing number.			
[Multi-Line Plain Text]			

Note: See www.fda.gov/cdrh for more information onmedical device premarket clearance procedures.

Document Key: Specialized Response content is defined within straight brackets []; Special code: [L] List of Values.

### Section: Report Identification

### 1.0 General Definitions

# **General Definitions**

This software application should be followed for all lasers and products containing, incorporating, or intended to incorporate, a laser or laser system [see the definition of "laser product" in section 21 CFR1040.10(b)(21)].

### Laser Reporting and Recordkeeping (21 CFR 1002)

Applicability of reporting and recordkeeping requirements for laser products:

Class I, IIa, II, and IIIa laser products and laser products containing such lasers will require: Product Report, Annual Report, test records, manufacturer's distribution records, and dealer/distributor distribution records.

Note that for Class I laser products containing lasers of Class I, IIa, II, or IIIa no Supplemental Reports are required. Furthermore, some Class I laser products have already been exempted from the requirement for distribution records (see Notice to Industry dated August 9, 1988, Laser Notice # 41).

Class IIIb and IV laser products require all of the above plus Supplemental Reports when the criteria requiring submission of Supplemental Reports are met.

The laser standard applies to all laser products manufactured after August 1, 1976 (1040.10(a)), unless the products are either: sold to a manufacturer for use as components (or replacements) in products that will be certified (1040.10(a)(1)); sold by or for a manufacturer as repair or replacement components if they are properly labeled as such and have installation instructions (1040.10)(a)(2)); or intended for export only, are labeled as such, and comply with the requirements of the importing country (1010.20). Manufacturers of laser products that are sold to other manufacturers for use as components in their products are required to register and list such products.

### Laser Definitions from 21 CFR 1040.10(b)

**Laser** means any product that can be made to produce or amplify electromagnetic radiation at wavelengths greater than 250 nm but less than or equal to 13,000 nm or, after August 20, 1986, at wavelengths equal to or greater than 180 nm but less than or equal to 1.0X106 nmprimarily by the process of controlled stimulated emission.

Laser energy source means any product intended for use inconjunction with a laser to supply energy for the operation of the laser. General energy sources such as electrical supply mains or batteries shall not be considered to constitute laser energy sources. Laser product means any manufactured product or assemblage of components which constitutes, incorporates, or is intended to incorporate a laser or laser system. A laser product is any device that constitutes, incorporates, or is intended to incorporate a laser or laser system (1040.10(b)(21)). A laser or laser system that is intended for use as a component of an electronic product shall itself be considered a laser product.

Laser radiation means all electromagnetic radiation emitted by a laser product within the spectral range specified in paragraph 1040.10(b)(19) that is produced as a result of controlled stimulated emission or that is detectable with radiation so produced through the appropriate aperture stop and within the appropriate solid angle of acceptance, as specified in 1040.10(e). Laser system means a laser in combination with an appropriate laser energy source with or without additional incorporated components. See paragraph 1040.10(e)(2) of the laser product performance standard for an explanation of the term "removable laser system."

### 2.0 Specific-Purpose Product Definitions

# Specific-Purpose Product Definitions

**Demonstration laser product** means any laser product manufactured, designed, intended, or promoted for purposes of demonstration, entertainment, advertising display, or artistic composition. The term "demonstration laser product" does not apply to laser products which are not manufactured, designed, intended, or promoted for such purposes, even though they may be used for those purposes or are intended to demonstrate other applications. Demonstration laser products (1040.10(b)(13)) include: laser products promoted for classroom demonstration of optical phenomena;

artistic displays and their associated apparatus;

laser light show projectors; and

laser light shows and displays themselves.

A general-purpose, scientific, medical or industrial laser product is not considered to be a demonstration laser product when it is demonstrated to a prospective purchaser. Demonstration laser products are restricted in their outputs to Class IIIa with its accompanying restrictions to Class I for short pulses and invisiblewavelengths(1040.11(c)). Because these levels are too low for effective use incommercial theatrical lighting effects, CDRH may grant variances (1010.4) to manufacturers of laser light shows and display devices. As a condition of the variance, the manufacturer must agree to adhere to several safety conditions to provide a level of safety to the publice quivalent to a fully compliant product. Consult the Compliance Guide for Laser Products, September 1985, Appendix B, Clarification of Certain Laser Light Show Requirements, for more information.

### 3.0 Show Name

What is (are) the name(s) of the light show or display?			
Item	Projector Model	Show Name	Brand or Trade Name
Item 1		Item 2	

### 4.0 Variance

Attach a copy of your variance application (FDA Form 3147) and/or, if approved, attach your variance approval letter (or variance number). Click on the Add... button below to attach any supporting files.

[HTML Text]

File Attachment

[Multiple File Attachments (.pdf, .jpg, .gif, .tif, .avi, .wmv, .xpt, .xml, .dtd, .sgml, .mol, .xls, .csv, .zip)]

> Is variance application attached?

[L]

> Is a copy of your variance approval letter attached?

[L]

### **Section: Equipment Information**

### 5.0 Projection Equipment

### Item: 1 (could contain up to 5 items with 1 required)

Or provide current variance number:

5.1	5.1 Manufacturer:	
> Model number or other designation:		
>	CDRH accession number:	

### 6.0 Show Venue

The lase	The laser light show or display takes place in:		
Item 1			
Item 2			
Item 3			
	>	If "other" has been selected, please specify:	

Note:

		unless certain drawings are general enough to cover more than one type. Drawings shall be attached following Part 9.0 Diagrams and Drawings of Show Venue.		
The lase	The laser light show or display takes place:			
Item 1				
Item 2				
Item 3				
	> If "	other" has been selected, please specify:		
7.0 Show Locations, Dates, and Times				
Item 3				

Be sure to provide beam path diagrams/floor plans for each of the types of venues listed above,

Note:	report approp submi manuf verbal phone submi CDRI-	e specific location(s), date(s), and time(s) for the show if this information is known at the time this ort is submitted. If not, advanced written notification must be made as early as possible to repriate Federal, State, and local authorities. To be considered timely, this written notice must be mitted 30 days prior to the opening of the show. When the show dates become known to the suffacturer less than 30 days prior to the show date, the required information must be provided hally by phone or by FAX to CDRH. A confirming formal written notice, including the date of the ne notification and the name of the CDRH individual to whom the information was given must be mitted within 14 days. Written confirmation would not be needed following a FAXed notification. RH must be notified of every show that your firm intends to produce. If notifications are not inely received in a timely manner your variance may be revoked.	
Click on the Add.	Click on the Add button below to attach any supporting files.		
File Attachment		[Multiple File Attachments (.pdf, .jpg, .gif, .tif, .avi, .wmv, .xpt, .xml, .dtd, .sgml, .mol, .xls, .csv, .zip)]	
Details		[HTML Text]	

### 8.0 Light Show Effects Produced

The lase	The laser light show uses the following laser effects:		
Item 1			
Item 2			
Item 3	tem 3		
If "other"	If "other" has been selected, please specify:		
[Multi-Lir	[Multi-Line Plain Text]		
Note:		Be sure that the beam path diagrams included in your response to Part 9.0 are sufficient to illustrate all of the effects indicated above. Several effects may be included in a single diagram.	

### 9.0 Diagrams and Drawings of Show Venue

Provide both plan and elevation drawings with dimensions of the show or display. If the setup varies from show to show, then provide this information for a typical show. \* If no drawings are attached, please add an explanation in the text box. Click on the Add... button below to attach any supporting files.

File Attachment	[Multiple File Attachments (.pdf, .jpg, .gif, .tif, .avi, .wmv, .xpt, .xml, .dtd, .sgml, .mol, .xls, .csv, .zip)]
[Multi-Line Plain Text]	

\*Be sure to include in the drawings:

- (1) the location of the projector(s) and control panel(s), audience, performer(s), operator(s), mirrors, mirror balls, display screens (or other targets), and beam termination points;
  - (2) the direct and reflected laser radiation beam path;
- (3) the laser radiation levels in each beam including the wavelength, maximum power, and scan parameters (if scanned) for the worst case from a human access point of view;
- (4) the minimum separations of the laser radiation fields (or beams) from reference locations in audience and performer areas in both vertical and horizontal directions; and
- (5) any direct or reflected beams into audience or performer locations.

Are drawings attached? [L]

### 10.0 Laser Radiation Levels

10.1 Describe how each of the laser radiation levels, indicated on the drawings attached in 9.0, were determined. If any levels were derived from calculations rather than directly measured, provide the actual calculations that were made. Click on the Add... button below to attach any supporting files.

File Attachment

[Multiple File Attachments (.pdf, .jpg, .gif, .tif, .avi, .wmv, .xpt, .xml, .dtd, .sgml, .mol, .xls, .csv, .zip)]

[Multi-Line Plain Text]

### 11.0 Scanning Safeguards

11.1 W	Will there be audience scanning* from any of the planned effects? [L]	
Note:	* Audience scanning is considered to be any scanning, projection, or reflection of laser or collateral radiation into audience or other accessible, uncontrolled area. Scattered radiation coming from diffuse reflectors such as fog, smoke, mist or similar diffusing media is not considered audience scanning. However, all radiation must be below Class I levels if it reaches into audience or other uncontrolled areas. A scanning safeguard is required whenever a laser light show includes audience scanning to assure that the laser radiation levels in audience areas will not exceed Class I limits if there is a scan failure. See the companion publication, "Compliance Guide for Laser Products," for further discussion.	nce
	Do any of the planned effects require laser radiation (direct or scanned beams) to be viewed by operators, performers, or employees?	
m so	> If the answer to 11.1 or 11.2 is yes, describe how the radiation levels that reach into audience areas are maintained at Class I levels by scanning. Your attached description must include details of the required scan failure safeguard, including a discussion of the means of detection of the scanning, the theory of the operation of the scanning safeguard, and its speed of response in order to show that it will prevent the scanned radiation from exceeding the Class I limits.	

	File Attachment	[Single File Attachment (.pdf, .jpg, .gif, .tif, .avi, .wmv, .xpt, .xml, .dtd, .sgml, .mol, .xls, .csv, .zip)]		
	[Multi-Line Plain Text]			
11.3	Will any laser radiation greater than Class I STRIKE BUT NOT BE VIEWED by operators, performers or other employees?			
>	Describe, in detail, the operation of the scan failure safeguard or other means which will prevent exposure to beams exceeding Class II. If a scan safeguard is used, include a discussion of the detection of scanning the operation, and the speed of response of the safeguard to show that it will prevent the scanned radiation from exceeding the limits of Class II. If other means are used, such as pressure pads or infared beams, describe in detail as well.			
	File Attachment [Single File Attachment (.pdf, .jpg, .gif, .tif, .avi, .wmv, .xpt, .xml, .dtd, .sgml, .mol, .xls, .csv, .zip)]  Details [Multi-Line Plain Text]			

### 12.0 Operator Controls

12.1	Is the show under the continuous control of an operator?		
12.2	Does the laser operator perform tasks in addition to operation of the laser projector?		
>	Describe those tasks:		
	[Multi-Line Plain Text]		
12.3	Can the operator see all of the propagating beam paths, their terminations and the audience at all times during the performance?		[L]
>	> Explain how adequate surveillance is provided:		
[Multi-Line Plain Text]		xt]	
12.4	Do any other personnel assist in providing surveillance of the laser display?		[L]
>	> State the number of persons, their identification (job titles), their duties, and how they assist in surveillance. Describe how they are in constant communication with the operator.		ng
	File Attachment	[Single File Attachment (.pdf, .jpg, .gif, .tif, .avi, .wmv, .xpt, .xml, .dtd, .sgml, .mol, .csv, .zip)]	.xls,
[Multi-Line Plain Text]			

# What qualifications\* are required of laser operators for your show?

### [HTML Text]

Note:

\* Holders of variances are required by the variance to employ trained operators or to assure that the operators receive adequate training to qualify them for the safe use of the laser projection system and presentation of the light show effects. Useful information including training films, reference books, and programs on the safe use of lasers may be obtained from the Laser Institute of America (LIA) and from the American National Standards Institute (request ANSI standard Z136.1).

12.6 If your show is not under the continuous control of an operator, is a person designated to be [L]

	responsible for the immediate termination of the laser radiation in the event of equipment malfunction, audience unruliness, or other unsafe conditions?
>	Explain alternate control:
	[Multi-Line Plain Text]
12.7	How is this person designated? What are his or her duties?
	[Multi-Line Plain Text]
12.8	What qualifications are required for this person?
	[Multi-Line Plain Text]

### 13.0 Projection Equipment Controls

13.1	Are one or more readily accessible controls provided to immediately terminate laser radiation?		[L]
>	Number of controls:		
13.2	Describe the location of these controls and their operation relative to your show.		
	[Multi-Line Plain Text]		

### **Section: Test and Notification Procedures**

### 14.0 Test Procedures

14.1	Attach a copy of the written setup, alignment, and test procedures to be followed prior to the operation of the laser light show at each location. If setup procedures are not a seperate form, provide a detailed description below of procedures that are followed. Click on the Add button below to attach any supporting files.			
	File Attachment	[Multiple File Attachments (.pdf, .jpg, .gif, .tif, .avi, .wmv, .xpt, .xml, .dtd, .s .xls, .csv, .zip)]	gml, .mol,	
	[Multi-Line Plain Text]			
14.2	When are these setup, alignment, and test procedures performed?			
	[Multi-Line Plain Text]			
14.3	What laser radiation levels are used during setup, alignment, and checkout? (in milliwatts)			
14.4	Is a written record of the results of the setup, alignment, and test procedures maintained?		[L]	
>	Explain how adequate quality assurance is maintained:			
	[Multi-Line Plain Text]			
>	You may attach records such as Standard Operating Procedures (SOPs), Quality Safety Checklists, and Daily Logs.		sts, and	

		Attachment	[Multiple File Attachments (.pdf, .jpg, .gif, .tif, .avi, .wmv, .xpt, .xml, .dtd, .sgml, .mol, .xls, .csv, .zip)]
		ils	[HTML Text]
laser projector(s mirror balls, and		laser projector(s mirror balls, and	dkeeping would include, but not limited to: (1) sketches showing the location of the s), operator(s), performer(s), audience, beam paths, viewing screens, wall mirrors, lother surfaces that may be struck by the laser beams; (2) information on scanning y, and frequency; and/or (3) laser radiation levels used in each effect.

### 15.0 Notification Procedures

15.1	What procedures are followed for notification of appropriate Federal (CDRH, FAA), State and local agencies? Either attach a file, form letters, or describe procedures in the text box below. Click on button to attach any supporting files.			
	File /	Attachment	[Multiple File Attachments (.pdf, .jpg, .gif, .tif, .avi, .wmv, .xpt, .xml, .dtd, .sgml, .mol, .xls, .csv, .zip)]	
	[Mult	i-Line Plain Text]		
What Federal, State and local agencies are notified or would be notified?				
Item 1				
Item 2				
Item 3				
Stop:		submission are packaged with y Report from the	ned the end of this report. Please verify that all PDFs that are to be included in this correctly attached to a specific file attachment question. Otherwise, they will not be your report. Check to make sure you have no missing data (select Missing Data Output menu). Once you have confirmed that there is no missing data and all your ed, click on the Package Submission icon on the tool bar.	
Message	:	Form FDA 3640	Reporting Guide for Laser Light Shows and Displays (03/06)	